



BUMPER GUARD INSTALLATION INSTRUCTIONS

Please Read Completely Before Starting

INSTALLATION

1. **Surface preparation:**

Prior to installation, make sure mounting surface is absolutely clean and free of wax, dirt, oil, etc. Areas not clean or dry prevent adhesive from fully bonding to mounting surface.

Note: Freshly painted surfaces should be fully cured before installation.

2. **Mounting:**

Before removing adhesive paper backing, position the bumper guards for exact placement.

Recommended: Installation Temperatures should be between 60°F and 90°F.

3. Peel off adhesive paper backing and mount.

4. Apply pressure to ensure good bonding. (If mounting tape is damaged due to removal after initial mounting or for any other reason, additional 3MTM two sided tape can be purchased at most auto parts stores.)

CAUTION: Do not subject BUMPER GUARD to extreme temperatures (as mentioned above), water or wind abuse for 12-24 hours after installation to ensure maximum bonding strength.