



BX1745

2021-2022 Chevy Tahoe/Suburban (No Diesel)
 (Includes Premier) (Includes ACC) (No Z71)
 2021-2022 GMC Yukon/Yukon XL (No Diesel)
 (Includes Denali) (Includes ACC) (No AT4)

Installation Instructions

Please read BOTH these Installation Instructions and the General Information sheet prior to installing or operating this equipment.

- Blue Ox® towing products and accessories are intended to be installed by Blue Ox® Dealers who are familiar with our products and have the equipment and knowledge necessary to do “fit work”. If needed, Blue Ox® Dealers can be found at www.blueox.com or by contacting our Technical Service Department at (402) 385-3051.
- Many Blue Ox® baseplates are designed to use existing holes and hardware to mount the baseplate to the towed vehicle. Even though bolts are there, do not assume they are adequate for baseplate mounting. Always use the hardware supplied in the hardware kit and existing hardware as specified in the installation instructions.

Serial Number


Attachment Tab Height: 19-1/2”

Attachment Tab Width: 18”

Bolt Torque Specifications

Torque in Foot-Pounds for Inch Bolts

Bolt Size	Grade 5	Grade 8
1/4”	10	14
5/16”	19	29
3/8”	33	47
7/16”	54	78
1/2”	78	119
5/8”	154	230
3/4”	257	380



Bolt Torque Specifications

Torque in Foot-Pounds for Metric Bolts

Bolt Size	Grade 8.8	Grade 10.9
6MM	6	8
8MM	16	22
10MM	31	40
12MM	54	70
14MM	89	117
16MM	161	230
18MM	222	318



If the front of your vehicle looks different than this, please contact us at (402)385-3051.



WARNING

Failure to read and follow these instructions could result in separation of the towed vehicle from the tow bar, causing property damage, loss of towed vehicle, personal injury or death.

Reference your vehicle owner’s manual for manufacturer’s towing specifications.

BX1745

2021-2022 Chevy Tahoe/Suburban (No Diesel) (Includes Premier) (Includes ACC) (No Z71)
2021-2022 GMC Yukon/Yukon XL (No Diesel) (Includes Denali) (Includes ACC) (No AT4)
Installation Instructions


Instruction Notes: The fascia cover and fascia are removed and reinstalled for the baseplate installation. Some drilling and trimming is required.

Place all components that are removed on a flat, sturdy surface. All items will be reinstalled unless otherwise noted after the baseplate is installed.


The dimensional variations between otherwise identical vehicles can be considerable. While the baseplate was designed for easy installation, it may be necessary to tailor the baseplate slightly to compensate for vehicle manufacturer's tolerances.

The BX8869 Tail Light Wiring Kit is recommended for vehicles with bulbs and the BX8848 Tail Light Wiring Kit is recommended for vehicles with LED Tail Lights.


Tail Light Removal:



Remove upper cover first (white), then lower cover (gray).



Using a T15 Torx, remove the one (1) upper screw and the one (1) lower screw from the tail light, Remove tail light.



For BX8869 Only: Drill a hole according to the tail light wiring kit instructions.

NOTICE


- Handling of some cosmetic parts when installing this product may require the use of protective covers, rags, specialty tools, etc. to prevent damage.
- When using power drills be aware of the dangers of torque and drill bit length.
- When using a reciprocating saw be aware of objects behind the cutting surface.
- Use a good quality paint to spray cut edges of frame to prevent rusting.
- Be sure that **ALL** electrical connections are plugged in and accessories are functioning properly before reinstalling the fascia.
- The baseplate is computer tested to your vehicle's GVWR, exceeding this weight will void the manufacturer's warranty.
- Be sure to use a sufficient amount of Loctite® Red on all bolt threads before tightening. Tighten all bolts according to the torque chart provided.
- Dealer or installer be certain the user receives these instruction sheets.
- If the baseplate is in an accident, it must be replaced. **DO NOT** use it again! An accident can cause unseen damage and using it again could result in more damage or serious injury. **DO NOT** use the baseplate if it is damaged or missing parts.

BX1745

2021-2022 Chevy Tahoe/Suburban (No Diesel) (Includes Premier) (Includes ACC) (No Z71)
 2021-2022 GMC Yukon/Yukon XL (No Diesel) (Includes Denali) (Includes ACC) (No AT4)
 Installation Instructions

Tools Required

Large Vise Grips	T15 Torx
Flat Screwdriver	T25 Torx
Torque Wrench	7MM Socket
Reciprocating Saw	10MM Socket
Drill	7/16" Socket
Loctite® RED	7/16" Wrench
1/2" Drill Bit	3/4" Socket
	3/4" Wrench




Item No.	Part No.	Description	Qty.
1.....	61-4029.....	1/2"-13 Whiz Nut w/ 10" Wire	8
2.....	61-8432.....	BX1745 Baseplate.....	1
3.....	62-3468.....	Attachment Tab Assembly with Hole	2
4.....	101-10408.....	Electrical Bracket.....	1
5.....	201-0050.....	1/4"-20 x 3/4" Hex Head Bolt, Grade 5, ZP	1
6.....	201-0051.....	1/2"-13 x 1-1/2" Hex Head Bolt, Grade 5, ZP	8
7.....	201-0192.....	#10-32 x 1/2" Round Slotted Head Screw	2
8.....	201-0979.....	#12-14 x 1" Self Drilling Screw, ZP.....	2
9.....	202-0047.....	#10-32 Hex Nut	2
10.....	202-0102.....	1/4"-20 Hex Nylon Nut, ZP	1
11.....	203-0012.....	1/2" Lock Washer, ZP	8
12.....	203-0054.....	#10 Lock Washer, ZP	2
13.....	226-0049(not shown).....	Class IV Safety Cables.....	2
14.....	229-0512(not shown).....	1/2" Quicklink, ZP	2
15.....	290-0437(not shown).....	Black Cap Plug Receiver.....	2

Important:


Use only genuine factory replacement parts on your baseplate. Do **NOT** substitute homemade or non-typical parts. If a bolt is lost or in need of replacement, for your safety and the preservation of your baseplate, be sure to use a replacement bolt of the same grade (In most cases it will be Grade 5, please reference the parts list above). Replacement parts may be ordered through your nearest Blue Ox® Dealer or Distributor. Failing to follow and/or altering these installation instructions in either installation or required equipment will void the manufacturer's warranty. Towing behind a non-motorized vehicle will void the warranty.

BX1745

2021-2022 Chevy Tahoe/Suburban (No Diesel) (Includes Premier) (Includes ACC) (No Z71)
2021-2022 GMC Yukon/Yukon XL (No Diesel) (Includes Denali) (Includes ACC) (No AT4)
Installation Instructions




1. Remove the nine (9) push pins (white) from the fascia cover. Using a T15 Torx, remove the two (2) screws from the hood latch handle (inset gray). Set aside the fascia cover and hood latch handle to be re-installed later.



2. Using a 10MM socket, remove the six (6) bolts from top of fascia.




3. Using a T15 Torx, remove the five (5) screws from the wheel well liner. Do this on both sides of the vehicle.




4. Carefully pull back wheel well liner. Using a 7MM socket, remove the one (1) bolt. Do this on both sides of the vehicle.

BX1745


2021-2022 Chevy Tahoe/Suburban (No Diesel) (Includes Premier) (Includes ACC) (No Z71)
2021-2022 GMC Yukon/Yukon XL (No Diesel) (Includes Denali) (Includes ACC) (No AT4)
Installation Instructions




5. Using a 7MM socket, remove the three (3) bolts from the lower belly pan side cover (white). Do this on both sides. Using a T15 Torx, remove the eight (8) screws from belly pan (gray). Four (4) on each side. Using 7MM socket, remove twelve (12) bolts from belly pan (black), six (6) on each side. Remove belly pan and side covers and set aside to be re-installed later.



6. Using a 10MM socket, remove the one (1) bolt. Do this on both sides of the vehicle.




7. ⚠ Gently pry the fascia loose from the front end. Carefully unplug two (2) electrical connections on the passenger side behind the fascia (inset). Remove the fascia from the vehicle and set aside.




- 8a. **Chevy Tahoe:** Remove two (2) white clips from cover behind fascia (white). Using a T25 Torx, remove two (2) screws from rear cover (gray). Using a 7MM socket, remove the remaining three (3) bolts from the rear cover (black). Remove cover and set aside. This will not be re-installed.

BX1745


2021-2022 Chevy Tahoe/Suburban (No Diesel) (Includes Premier) (Includes ACC) (No Z71)
2021-2022 GMC Yukon/Yukon XL (No Diesel) (Includes Denali) (Includes ACC) (No AT4)
Installation Instructions




8b. **GMC Yukon:** Remove four (4) white clips from cover behind fascia (white). Using a 7MM socket, remove five (5) bolts from the rear cover (gray). Remove cover and set aside. This will not be re-installed.



9a. **Models With ACC:** Using a saw, remove the side flange from Adaptive Cruise Control (ACC) mounting bracket.




9b. **Models With ACC:** Using a 7MM socket, remove the four (4) mounting bolts from the ACC and allow to hang out of the way. This will be re-installed later.
Note: DO NOT unplug ACC sensor as it may trip error code on the vehicle.




10. Using a saw, cut the two (2) vertical supports of the mounting bracket for the belly pan approximately 2" from the top and flush with the top of the lower cross member. Remove the cutout pieces.

BX1745


2021-2022 Chevy Tahoe/Suburban (No Diesel) (Includes Premier) (Includes ACC) (No Z71)
2021-2022 GMC Yukon/Yukon XL (No Diesel) (Includes Denali) (Includes ACC) (No AT4)
Installation Instructions




11. Slide baseplate into place. Using one (1) supplied 1/2" bolt on each side, insert into an existing hole to locate baseplate and hold in place. Using a vise grip, clamp baseplate firmly against bottom of frame on both sides.



12. On passenger side only, mark the two (2) rear holes on the side of the frame that need to be drilled through. Remove baseplate and set aside. Using a 1/2" drill bit, drill two (2) holes into the side of the frame.



13. Slide baseplate back into place. Using one (1) 1/2" bolt on each side, insert into an existing hole to hold in place. Again, clamp baseplate firmly against bottom of frame on both sides. Install three (3) 1/2" x 1-1/2" bolts with lock washers and wire nuts in the side mounting holes. Tighten fully. Do this on both sides of the vehicle.




14. Using a 1/2" drill bit and the baseplate holes as a guide, drill the one (1) hole through the bottom of the frame. Do this on both sides. Install 1/2" x 1-1/2" bolt with lock washer and wire nut in bottom mounting hole. Tighten fully. Do this on both sides of the vehicle.


**** Use Loctite® Red on all bolt threads and tighten all bolts to the appropriate torque. ****

BX1745

2021-2022 Chevy Tahoe/Suburban (No Diesel) (Includes Premier) (Includes ACC) (No Z71)
2021-2022 GMC Yukon/Yukon XL (No Diesel) (Includes Denali) (Includes ACC) (No AT4)
Installation Instructions



15. **Models With ACC:** Re-install the ACC bracket.



16. Attach the permanent baseplate safety cables to the provided convenience link on the baseplate. The photo above shows the recommended installation of the cables to frame of vehicle. Additional options may interfere with suggested mounting; in this case, secure the cables to a solid piece of the frame as described in the General Information sheet. Be sure the safety cables do not rub against any hoses or moving parts. Do this on **BOTH** sides of the vehicle.



17. Hold the fascia as close to its original position as possible. Mark and trim the fascia as needed for clearance with the baseplate components. Reinstall the fascia and fascia covers.



BX1745

2021-2022 Chevy Tahoe/Suburban (No Diesel) (Includes Premier) (Includes ACC) (No Z71)
2021-2022 GMC Yukon/Yukon XL (No Diesel) (Includes Denali) (Includes ACC) (No AT4)
Installation Instructions

CUSTOMER SERVICE COMMITMENT

Blue Ox® is committed to providing you with exceptional customer care throughout your lifetime with our products. Our team is here to assist you with any questions you may have regarding the performance of your product. Simply call (402) 385-3051 and you can speak with our technical service team.

Additionally, please visit our website to see which rallies our Destination America team will be attending. For a nominal fee, our service technician will service your towing system to ensure it's in proper working condition. Also, as a commitment to our customers, should you visit our factory, you can stay at our full service Blue Ox® campground at no charge along with enjoying a factory tour.

Again, thank you for being our customer and for the confidence you have shown in the performance of our products. It is because of customers like you we enjoy the success we have today.



© 2015 Blue Ox
One Mill Road, Industrial Park
Pender, Nebraska 68047
Phone: (402) 385-3051
Fax: (402) 385-3360
www.blueox.com

General Information

1. Ensure that your product(s) are registered online at www.blueox.com. It is crucial to register your product(s) so that you may be alerted of product offerings, updates, upgrades, maintenance and safety bulletins, and/or recalls.
2. **It is the owner's responsibility to inspect all towing equipment for cracked welds, missing or worn parts and loose bolts before each towing trip.** Be sure to use Loctite® Red on all bolts and tighten to the recommended specifications.
3. **It is the owner's responsibility to hook up all towing equipment per manufacturer's instructions/recommendations.**
4. Remove the attachment tabs when not in use (if applicable).

Notice To Baseplate Installer

1. It is YOUR responsibility to watch for:

- Oil cooler and air conditioner lines
- Electrical wires and hoses
- Missing parts or attaching points on the frame

** If the baseplate is improperly installed and is against a wire or hose, it could cause fluid leaks or electrical shorts some time after the actual baseplate installation.

Permanent Baseplate Safety Cable Installation

Permanent baseplate safety cables are strongly recommended when towing a vehicle with a tow bar. The principle function of the permanent baseplate safety cables is to prevent the towed vehicle from breaking loose in the event the connection between the frame of the towed vehicle and the baseplate fails or becomes disconnected. The cables must be connected from the baseplate to the frame rail or cross member of the vehicle's frame. The illustrations below show the possible arrangements recommended by Blue Ox®. Each permanent baseplate safety cable must have an adequate weight rating for the towing system. The weight rating of the two (2) cables together will not qualify.

Do not mount the permanent baseplate safety cables against wires, hoses or brake lines.

These permanent baseplate safety cables should remain installed as long as the baseplate is installed on the vehicle. Permanent baseplate safety cables are to be used in conjunction with, and NOT a replacement for legally required safety cables attaching the towed vehicle to the towing vehicle.


Option #1

(Baseplates with Convenience Link Tabs)



Option #2

(Baseplates with out Convenience Link Tabs)



BLUE OX ORIGINAL PURCHASERS THREE YEAR LIMITED WARRANTY

Automatic Equipment Manufacturing Company ("Automatic") warrants to the original (first) retail purchaser that this product, manufactured by Automatic, shall be free from defect in material and workmanship under normal use and service for a period of three years from the date of delivery.

During said three-year period, Automatic will repair or replace any parts that have been returned by the original purchaser, to the factory, transportation prepaid, and in Automatic's sole and absolute opinion found to be defective.

Limitations on Warranty Coverage:

Coverage under this warranty will be valid only if the customer warranty card is returned by the original purchaser within 30 days of purchase.

Coverage under this warranty will be effective only when a copy of the original invoice, showing date and place of purchase, accompanies any claim for warranty. This warranty is NON TRANSFERABLE.

This limited warranty will not cover, in any way or form, any alleged damages caused by incorrect or improper installation, improper use, modification or neglect of product, failure to properly service and maintain, misuse, act of God, accident or failure of the user to follow guidelines contained in the instructional material provided by Automatic.

This warranty does not cover normal wear and tear, paint or rust.

Warrantor assumes no responsibility to the owner for loss of use of product, loss of time, inconvenience or any other damage consequential or otherwise. Including, but not limited to mileage, expense of transporting of product, return shipping expense, mechanics travel time, telephone, road service, towing, and rental during repairs, travel, lodging, loss or damage to personal property or loss of earnings.

REPAIR OR REPLACEMENT AS SET FORTH IN THIS LIMITED WARRANTY IS THE SOLE EXCLUSIVE REMEDY OF THE PURCHASER. AUTOMATIC SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN LENGTH TO THE DURATION OF THIS WARRANTY.

Please visit <http://blueox.com/warranty/> to register your warranty



BLUE OX