

HITCH WEIGHT: <u>14</u> LBS.
INSTALL TIME
PROFESSIONAL: <u>15</u> MINUTES
NOVICE (DIY): <u>30</u> MINUTES
INSTALL NOTES:
- NO DRILLING REQUIRED
- FISHWIRE HARDWARE

INSTALLATION STEPS

- 1. Remove existing trailer ball hole cap on center of bumper and return to vehicle owner.
- 2. Raise the hitch into position and secure with 3/4-10 x 3 1/4" flat head socket cap screw through the bumper and bumper support into the hitch.
- 3. Fishwire 1/2-13 carriage bolts and CM-SP4 spacers through the end of the bumper support tube and into each mount hole of the hitch. (See Fishwire Technique.)
- 4. Secure hitch to bumper support with 1/2-13 hex flange nuts.
- 5. Torque all 1/2" hardware to 110 lb-ft and all 3/4" hardware to 380 lb-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Keystone Automotive Operations Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Keystone Automotive Operations Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Keystone Automotive Operations Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684. For Technical & Warranty Support: 1-877-544-4449 Fax-1-855-242-8922 www.huskytow.com