Please visit www.blueox.com for the latest version of these installation instructions.



BX1856 2020-2023 Nissan Versa Sedan (Manual Only) (Includes Intelligent Cruise Control) (No Fog Lights) Installation Instructions

Please read BOTH these Installation Instructions and the General Information sheet prior to installing or operating this equipment.

- Blue Ox[®] towing products and accessories are intended to be installed by Blue Ox[®] Dealers who are familiar with our products and have the equipment and knowledge necessary to do "fit work". If needed, Blue Ox[®] Dealers can be found at www.blueox.com or by contacting our Technical Service Department at (402) 385-3051.
- Many Blue Ox[®] baseplates are designed to use existing holes and hardware to mount the baseplate to the towed vehicle. Even though bolts are there, do not assume they are adequate for baseplate mounting. Always use the hardware supplied in the hardware kit and existing hardware as specified in the installation instructions.





If the front of your vehicle looks different than this, please contact us at (402)385-3051.

Serial Number

Attachment Tab Height: 15"

Attachment Tab Width: 22"

Bolt Torque Specifications Torque in Foot-Pounds for Inch Bolts								
Bolt Size	Grade 5	Grade 8						
1/4"	10	14						
5/16"	19	29						
3/8"	33	47						
7/16"	54	78						
1/2"	78	119						
5/8"	154	230						
3/4"	257	380						

Bolt Torque Specifications								
	3/4"	257	380					
	0/4"	057	200					
	5/8"	154	230					
	1/2"	78	119					

Torque in Foot-Pounds for Metric Bolts						
Bolt Size	Grade 8.8	Grade 10.9				
6MM	6	8				
8MM	16	22				
10MM	31	40				
12MM	54	70				
14MM	89	117				
16MM	161	230				
18MM	222	318				

A WARNING

Failure to read and follow these instructions could result in separation of the towed vehicle from the tow bar, causing property damage, loss of towed vehicle, personal injury or death.

Reference your vehicle owner's manual for manufacturer's towing specifications.

Instruction Notes: The fascia and bumper are removed and reinstalled for the baseplate installation. Some drilling and trimming is required.


Place all components that are removed on a flat, sturdy surface. All items will be reinstalled unless otherwise noted after the baseplate is installed.

The dimensional variations between otherwise identical vehicles can be considerable. While the baseplate was designed for easy installation, it may be necessary to tailor the baseplate slightly to compensate for vehicle manufacturer's tolerances.

The BX8848 Tail Light Wiring Kit is recommended for this vehicle.

NOTICE

- Handling of some cosmetic parts when installing this product may require the use of protective covers, rags, specialty tools, etc. to prevent damage.
- When using power drills be aware of the dangers of torque and drill bit length.
- When using a reciprocating saw be aware of objects behind the cutting surface.
- Use a good quality paint to spray cut edges of frame to prevent rusting.
- Be sure that **ALL** electrical connections are plugged in and accessories are functioning properly before reinstalling the fascia.
- The baseplate is computer tested to your vehicle's GVWR, exceeding this weight will void the manufacturer's warranty.
- Be sure to use a sufficient amount of Loctite[®] Red on all bolt threads before tightening. Tighten all bolts according to the torque chart provided unless specified.
- Dealer or installer be certain the user receives these instruction sheets.
- If the baseplate is in an accident, it must be replaced. DO NOT use it again! An accident can cause unseen damage and using it again could result in more damage or serious injury. DO NOT use the baseplate if it is damaged or missing parts.



Item No.	Part No.	Description	Qty.
1	61-4029	1/2"-13 Whiz Nut w/ 10" Wire	2
2	61-4978	3/8"-16 Whiz Nut w/ 14" Wire	2
3	61-5208	3/8" Nut Plate w/ 14" Wire	2
		BX1856 Baseplate	
5		Attachment Tab Assembly with Hole	2
6	101-10394	1/4" x 1-7/8" Angle Bracket Plate w/Holes	2
		3/4" OD x 1/2" ID x 1/2" Tube	
8	201-0050	1/4"-20 x 3/4" Hex Head Bolt, Grade 5, ZP	1
9		#10-32 1/2" Round Slotted Head Screw	2
		1/2"-13 x 2: Hex Head Bolt, Grade 5, ZP	
11		3/8"-16 x 1-1/4" Hex Head Bolt, Grade 5, ZP	4
		1/2"-13 x 3-1/2" Hex Head Bolt, Grade 5, ZP	
		8MM-1.25 x 30 MM Hex Head Bolt, Grade 8.8, ZP.	
		#12-14 x 1" Self Drilling Screw, ZP	
15		#10-32 Hex Nut	2
		1/2"13 Hex Nylon Insert Lock Nut, ZP	
		1/4"-20 Hex Nylon Nut, ZP	
		8MM-1.25 Hex Nut, ZP	
		1/2" Flat Washer, ZP	
20		3/8" Lock Washer, ZP	4
		1/2" Lock Washer, ZP	
		#10 Lock Washer, ZP	
		8MM Lock Washer, ZP	
		8MM Flat Washer, ZP	
		4-Way Bracket	
		Class III Safety Cables	
	()	3/8" Quicklink, ZP	
		8" Nylon Cable Tie	
29	290-0437(not shown)	Black Cap Plug Receiver	2

Important:

Use only genuine factory replacement parts on your baseplate. Do **NOT** substitute homemade or non-typical parts. If a bolt is lost or in need of replacement, for your safety and the preservation of your baseplate, be sure to use a replacement bolt of the same grade (In most cases it will be Grade 5, please reference the parts list above). Replacement parts may be ordered through your nearest Blue Ox® Dealer or Distributor. Failing to follow and/ or altering these installation instructions in either installation or required equipment will void the manufacturer's warranty. Towing behind a non-motorized vehicle will void the warranty.




1. Using a 10MM socket, remove the two (2) bolts from the top of the fascia (white). Then remove the four (4) push pins, two (2) on each side (gray)



2. Using a flat head screw driver, pull back the wheel well liner. Then using a 10MM socket, remove the one (1) bolt. Do this on both sides of the vehicle.




3. Using a Phillips screw driver, remove the three (3) screws from the underside of the fascia. Do this on both sides of the vehicle.



 Using a 10MM socket, remove the two (2) bolts from the underside of the fascia (white). Then remove the four (4) push pins (gray). Remove fascia and set aside to be reinstalled later.




5. Remove the Styrofoam piece from the bumper. It will not be reinstalled.



 Using a 13MM socket, remove the four (4) nuts from the bumper. Do this on both sides of the vehicle. Disconnect push pin on the back side of the bumper on the passenger side of the vehicle. Remove bumper and set aside to be reinstalled later.

Note: For vehicles with Intelligent Cruise Control (ICC), flip bumper up and set on top of motor so ICC does not need to be disconnected.




7. Remove the temperature sensor from the plastic shielding on the driver side of the vehicle. It will be repositioned later.






8. Using a utility knife, trim the plastic shielding on both sides of the vehicle as indicated.




9. Using a 1-1/4" hole saw, drill two (2) access holes. Do this on both sides of the vehicle.




Using a 13MM socket, remove the four

 (4) bolts (white) from the horn extension
 on the passenger side of the vehicle.
 Remove horn extension. It will be bolted to
 the baseplate before reinstallation.


On the driver side of the vehicle, use a 10MM socket to remove the bottom outer bolt on the frame extension (inset).




11. Using two (2) 1/2" bolts with hardware, loosely attach the horn extension to the passenger side of the baseplate.



12. Slide the baseplate into place and start the front two (2) 1/2" bolts with hardware on the drive side of the vehicle. Then reinstall the 6MM bolt into the bottom outer hole on the frame extension (inset).




 Reinstall the horn extension on the passenger side of the vehicle using only three (3) of the existing bolts. The bottom outer bolt on both sides of the vehicle will be installed later using supplied hardware.



- 14. Place 1/2" spacer between baseplate and frame. Insert 1/2" bolt with hardware. Do this on both sides of the vehicle. Tighten all hardware at this time
- ** Use Loctite[®] Red on all bolt threads and tighten all bolts to the appropriate torque.**




15. Using a 3/8" drill bit, drill the back hole of the baseplate. Install one (1) 3/8" bolt with hardware. Do this on both sides of the vehicle.




 Insert the supplied 8MM bolt into the bottom outer hole of the frame extension. Attach hardware and angle bracket. Do this on both sides of the vehicle.

** Use Loctite® Red on all bolt threads and tighten all bolts to the appropriate torque.**



- 17. Using a 3/8" drill bit, drill a hole into the frame using the angle bracket as a guide. Install 3/8" bolt with hardware. Do this on both sides of the vehicle.
 - ** Use Loctite[®] Red on all bolt threads and tighten all bolts to the appropriate torque.**



 Attach the temperature sensor to the baseplate on the driver side of the vehicle using the supplied zip tie.



19. Attach the permanent baseplate safety cables to the provided convenience link on the baseplate. The photo above shows the recommended installation of the cables to frame of vehicle. Additional options may interfere with suggested mounting; in this case, secure the cables to a solid piece of the frame as described in the General Information sheet. Be sure the safety cables do not rub against any hoses or moving parts. Do this on **BOTH** sides of the vehicle.



20a. **2020-2022 Models**: Using a reciprocating saw, remove the indicated piece of the fascia to allow room for the baseplate. Do this on both sides of the fascia.



20b. **2023 Models**: Using a reciprocating saw, remove the indicated piece of the fascia to allow room for the baseplate. Do this on both sides of the fascia.



21. **2023 Models**: The bottom black piece on fascia may need to be notched for baseplate clearance. Hold the fascia as close to its original position, mark and trim the fascia around the attachment tabs.





22. Reinstall the bumper and reconnect all electrical. Reinstall fascia.

CUSTOMER SERVICE COMMITMENT

Blue Ox® is committed to providing you with exceptional customer care throughout your lifetime with our products. Our team is here to assist you with any questions you may have regarding the performance of your product. Simply call (402) 385-3051 and you can speak with our technical service team.

Additionally, please visit our website to see which rallies our Destination America team will be attending. For a nominal fee, our service technician will service your towing system to ensure it's in proper working condition. Also, as a commitment to our customers, should you visit our factory, you can stay at our full service Blue Ox® campground at no charge along with enjoying a factory tour.

Again, thank you for being our customer and for the confidence you have shown in the performance of our products. It is because of customers like you we enjoy the success we have today.

© 2016 Blue Ox One Mill Road, Industrial Park Pender, Nebraska 68047 Phone: (402) 385-3051 Fax: (402) 385-3360 www.blueox.com

General Information

- Ensure that your product(s) are registered online at www.blueox.com. It is crucial to register your product(s) so that you may be alerted of product offerings, updates, upgrades, maintenance and safety bulletins, and/ or recalls.
- 2. It is the owner's responsibility to inspect all towing equipment for cracked welds, missing or worn parts and loose bolts before each towing trip. Be sure to use Loctite[®] Red on all bolts and tighten to the recommended specifications.
- 3. It is the owner's responsibility to hook up all towing equipment per manufacturer's instructions/ recommendations.
- 4. Remove the attachment tabs when not in use (if applicable).

Notice To Baseplate Installer

- 1. It is YOUR responsibility to watch for:
 - Oil cooler and air conditioner lines
 - Electrical wires and hoses
 - Missing parts or attaching points on the frame

** If the baseplate is improperly installed and is against a wire or hose, it could cause fluid leaks or electrical shorts some time after the actual baseplate installation.

Permanent Baseplate Safety Cable Installation

Permanent baseplate safety cables are strongly recommended when towing a vehicle with a tow bar. The principle function of the permanent baseplate safety cables is to prevent the towed vehicle from breaking loose in the event the connection between the frame of the towed vehicle and the baseplate fails or becomes disconnected. The cables must be connected from the baseplate to the frame rail or cross member of the vehicle's frame. The illustrations below show the possible arrangements recommended by Blue Ox®. Each permanent baseplate safety cable must have an adequate weight rating for the towing system. The weight rating of the two (2) cables together will not qualify.

Do not mount the permanent baseplate safety cables against wires, hoses or brake lines.

These permanent baseplate safety cables should remain installed as long as the baseplate is installed on the vehicle. Permanent baseplate safety cables are to be used in conjunction with, and NOT a replacement for legally required safety cables attaching the towed vehicle to the towing vehicle.



BLUE OX ORIGINAL PURCHASERS THREE YEAR LIMITED WARRANTY

Automatic Equipment Manufacturing Company ("Automatic") warrants to the original (first) retail purchaser that this product, manufactured by Automatic, shall be free from defect in material and workmanship under normal use and service for a period of three years from the date of delivery.

During said three-year period, Automatic will repair or replace any parts that have been returned by the original purchaser, to the factory, transportation prepaid, and in Automatic's sole and absolute opinion found to be defective.

Limitations on Warranty Coverage:

Coverage under this warranty will be valid only if the customer warranty card is returned by the original purchaser within 30 days of purchase.

Coverage under this warranty will be effective only when a copy of the original invoice, showing date and place of purchase, accompanies any claim for warranty. This warranty is NON TRANSFERABLE.

This limited warranty will not cover, in any way or form, any alleged damages caused by incorrect or improper installation, improper use, modification or neglect of product, failure to properly service and maintain, misuse, act of God, accident or failure of the user to follow guidelines contained in the instructional material provided by Automatic.

This warranty does not cover normal wear and tear, paint or rust.

Warrantor assumes no responsibility to the owner for loss of use of product, loss of time, inconvenience or any other damage consequential or otherwise. Including, but not limited to mileage, expense of transporting of product, return shipping expense, mechanics travel time, telephone, road service, towing, and rental during repairs, travel, lodging, loss or damage to personal property or loss of earnings.

REPAIR OR REPLACEMENT AS SET FORTH IN THIS LIMITED WARRANTY IS THE SOLE EXCLUSIVE REMEDY OF THE PURCHASER. AUTOMATIC SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN LENGTH TO THE DURATION OF THIS WARRANTY.

Please visit http://blueox.com/warranty/ to register your warranty

